

MIRALITE PURE ECOLOGICAL MIRROR

List of validated glues for MIRALITE PURE installation

	BRAND REFERENCE
1	ATE SBR Bond
2	Beko Tackcon
3	Bohle MS Polymer
4	Bostik Xtrem'Fast = MSP 113 Miroirs
5	Bostik Sil Espejos
6	Bostik MSP 108 GTI
7	CRL Evergrip Mirror Adhesive EG310
8	Danalim Turbo Tack 291
9	Den Braven Hercuseal Sealer 302
10	Den Braven Hybrifix 611 - Microfix MS
11	Den Braven Mamut High Tack*
12	DL Chemicals Paracol Miroseal MS
13	Dow Corning 817 High Modulus Adhesive
14	EGO Der Spiegelkleber
15	EGO MS 812
16	Fratelli Zucchini MS Super
17	Hodgson Mirror Adhesive
18	Illbrück SP050
19	Illbrück SP141
20	Intecnia Silcosell C-621
21	Kawo SK86
22	Krafft Silkra Espejos
23	Lakma do luster ekologicznych
24	Lakma do luster*
25	Marston-Domsel MS Polymer
26	Olivé G-64
27	Otto-Chemie Novasil S802
28	Otto-Chemie Novasil SP 5737
29	Otto-Chemie Ottocoll M501
30	Otto-Chemie Ottocoll S16
31	Pattex SL 618 Solyplast
32	Ramsauer 660 Spiegelkleber
33	Quilosa Orbasil N32
34	Sika Sikaflex 118
35	Soudal Mirror Fix
36	Soudal Silirub 2S
37	Würth MS Miroir
38	Würth MS Instant Espejos



SAINT-GOBAIN GLASS is not a manufacturer of the installation materials, it does not guarantee their neutrality, and it bears no responsibility for properties specified in the instruction of the installation products. In the event of doubt run a test in compliance with the user's manual provided by the manufacturer of the installation materials. In all cases mirror's installation must be in compliance with the user's manual provided by the manufacturer of the installation materials. More info on processing and installation of MIRALITE PURE in the Processing Guidelines.

MIRALITE PURE ECOLOGICAL MIRROR

List of validated tapes for MIRALITE PURE installation

	BRAND REFERENCE
1	3M 4032
2	3M 4910F
3	Adhex P270
4	CEYS Montack
5	Mactac Macmount M 1702 BP
6	Lohmann DuploCOLL 370
7	Lohmann DuploCOLL 50031 = Lohmann 230
8	Lohmann DuploCOLL 5009
9	Lohmann DuploCOLL 5015
10	Pattex No más clavos
11	Raytech Supermount
12	Saint-Gobain PPL H-Old 8920
13	Saint-Gobain PPL Norbond V1500
14	Scapa 5474
15	Stokvis S70 100
16	Tesa ACX plus
17	Tesa Powerbond
18	Tesa Powerstrip
19	Würth Mirror Adhesive Tape
20	Viba 6606
21	Vito Vitomount A8213
22	Vito Vitomount SU 100 FBL 2



SAINT-GOBAIN GLASS is not a manufacturer of the installation materials, it does not guarantee their neutrality, and it bears no responsibility for properties specified in the instruction of the installation products. In the event of doubt run a test in compliance with the user's manual provided by the manufacturer of the installation materials. In all cases mirror's installation must be in compliance with the user's manual provided by the manufacturer of the installation materials. More info on processing and installation of MIRALITE PURE in the Processing Guidelines.